



AQUA SHOT

OWNERS MANUAL





Please read this owner's manual before assembling the basketball hoop. It is vital to your safety and to the safety of others that you follow the instructions contained in this manual.

If you have any questions, you may contact us as follows:

The WaterWays, LLC

thewaterways2023@gmail.com

ASSEMBLY INSTRUCTIONS AVAILABLE AT:

www.thewaterwayssports.com

TABLE OF CONTENTS

Introduction.....
Intended Use.....
Safety.....
Boat Specifications for Approved Mounting.....
Approved and Unapproved Mounting Locations.....
Assembly Mounting Hardware.....
Daily Assembly Procedure.....
Docking and Storage.....
Care and Maintenance.....
Return Authorization Policy.....
Limited Warranty.....

PACKAGE CONTENTS: BASKETBALL WITH PUMP AND BALL

- Backboard
- Backboard Foam
- Rim
- Net
- Rim Hardware
- (2) Hooks
- Hook Hardware
- Hook Foam
- #5 Ball
- 6-inch Ball Pump
- Manual/ Instructions

Make sure you have received all the contents listed above before assembling.

]

INTRODUCTION

Water sports can be safe and fun for all levels of enthusiasts. The Manual is presented to enhance your enjoyment of this product and to alert you to dangerous conditions that can arise in any water sports.

Read this manual before assembling and using the product. Although the product is simple to use, this manual contains important safety information that you and all users must understand about this product before using.

If you have any questions regarding this product, you may contact The WaterWays, LLC at thewaterways2023@gmail.com. Please have your order purchase number available.



**UNSAFE USE OF THE AQUA SHOT BASKETBALL HOOP CAN
RESULT IN PERSONAL INJURY OR DEATH.**

To reduce the risk of injury, read and follow all instructions and warnings in this manual

Do not use this product unless you understand this Manual and accept the risks of injury.

INTENDED USE INSTRUCTIONS

To ensure that you, your family, and guest are able to safely enjoy your Aqua Shot for many years, it is critical that you adhere to the following instructions every time you use your Aqua Shot. Contact The WaterWays, LLC at thewaterways2023@gmail.com with any questions about the safe use of your Aqua Shot basketball hoop.

DO

- Fully read your owner's manual before installing and using the product.
- **MAKE SURE THAT THE WATER IS OF PROPER DEPTH (15 FEET MINIMUM) AND FREE OF OBSTRUCTIONS BEFORE JUMPING.**
- Secure boat's location before using your Aqua Shot
- Make sure the hardware is correctly fastened and properly positioned.
- Know the topography of the Landscape below the water before jumping.
- Continually check the depth of the water for proper depth use.
- Make sure that all family members and guests are familiar with these instructions before they use your Aqua Shot.
- Make sure that the Aqua Shot has been assembled in compliance with the assembly instructions.
- Plan your path to be sure you avoid any other swimmers, or objects in or under the water.
- **MAKE SURE THAT ANY CHILD OR ANY NON-SWIMMERS ARE SUPERVISED AT ALL TIMES AND WEARING USCG APPROVED LIFE VEST.**

- Jump from deck of boat only.
- Inspect your Aqua Shot before each day of use and keep them in proper repair.
- **USE ONLY UNDR MATURE, ADULT, SUPERVISION.**
- **Remove before docking.**

DON'T

- DONT USE THIS PRODUCT IN LESS THEN 15 FEET OF WATER! MOST DEBILITATING SPINAL CORD INJURIES THAT OCCUR WHILE SWIMMING INVOLVE JUMPING INTO SHALLOW WATER! JUMPING INTO SHALLOW WATER PRODUCES SERIOUS RISK OF BROKEN BONES, CUTS, NERVE DAMAGE, SPINAL CORD INJUSRIES OR BRAIN INJURY, OR DEATH.
- DO NOT USE ALCHOLIC BEVERAGES IN CONNECTION WITH THE AQUA SHOT.
- Never use this product after sunset, before dawn, or in any poor lighting conditions.
- Never use the product in rough water conditions, during storms, or when there is lightning.
- Don't run and jump or use while the boat is in motion.
- Don't engage in horseplay on or around the Aqua Shot.
- Don't use your Aqua Shot as a base for any chains, ropes, or lanyards.

- Don't attempt any competitive jumps from the deck of the boat. Keep all jumps simple and forward.
- Don't jump into or through objects or toys.
- Don't use your Aqua Shot if any part is showing signs of corrosion, appears worn-out or in need of repair.
- Don't leave the Aqua Shot mounted on boat when docking.
- DO NOT DUNK ON HOOP!

SAFETY FIRST!

The Aqua Shot shall only be assembled under the specifications outlined in the instructions and thewaterwaysports.com. Installation instructions provided by The WaterWays, LLC must be diligently followed.

The Aqua Shot basketball hoop that is improperly assembled can be dangerous to the user resulting in possible serious injury, including injuries to, head and limbs.

All users must follow all warnings provided with the Aqua Shot baseball hoop. All the warnings must be posted. If not provided or they are

misplaced, please contact The WaterWays, LLC immediately and post them in the proper location as depicted below.

The following LABEL must be clearly displayed on your Aqua Shot at all time

**This product is not designed to hang or dunk on
for the safety of you and others.**

NOTICE

ALL MOUNTING HARDWARE AND ASSEMBLY INSTRUCTIONS & VIDEOS ARE AVAILABLE AT:

thewaterwayssports.com

Return and Refund Policy

At The WaterWays, we strive to provide our customers with high-quality products. We understand that there may be instances where you need to return or seek a refund for your purchase. Our return and refund policy is designed to accommodate such situations while ensuring a fair and transparent process. Please review the following guidelines:

1. Eligibility for Returns:
 - Products must be returned within 14 days from the date of purchase.
 - The product must be unused, undamaged, and in its original packaging.
 - Proof of purchase, such as an order number or receipt, is required.
2. Return Process:
 - To initiate a return, please contact our customer support team
 - Provide your order details and the reason for the return.
 - Our customer support team will guide you through the return process, including any necessary shipping instructions.
3. Refund Process:
 - Once we receive the returned product and verify its condition, we will initiate the refund process.
 - Refunds will be issued in the same form of payment used during the original purchase.
 - Please allow 14 business days for the refund to reflect in your account.
4. Non-Returnable Items:

Certain items are not eligible for return or refund, including:

- Products that have been used, damaged, or are not in their original packaging.
- 5. Shipping Costs:
 - 6. Customers are responsible for the shipping costs associated with returns unless the return is due to an error on our part.
 - 7. If you received a damaged or defective product, we will cover the return shipping costs.
- 8. Damaged or Defective Products:
 - If you receive a damaged or defective product, please contact our customer support immediately.
 - We may request supporting documentation or photographs to assess the damage or defect.
 - We will either provide a replacement, issue a refund, or offer an alternative solution based on product availability and your preference.

Please note that this Return and Refund Policy applies only to purchases made directly from Thewaterwayssports.com. If you purchased our products through a third-party retailer, please refer to their respective return and refund policies.

If you have any further questions or concerns regarding our return and refund policy, please don't hesitate to reach out to our customer support team

**FOR TECHNICAL SUPPORT OR ASSISTANCE CONTACT
CUSTOMER SERVICE AT:**

THEWATERWAYSSPORTS.COM

THEWATERWAYS2023@GMAIL.COM